

Safety Warnings and Legal Notifications

As with most electrical products, you should keep the Zen Flute away from water and sources of heat such as radiators or the like. If the Zen Flute gets wet, immediately disconnect it from power and turn off the power switch and allow it to thoroughly dry. When charging the Zen Flute, use the included USB cable and an approved 5 V USB compatible power source.

When the mouthpiece is removed for cleaning, the speaker membrane (square of silver foil) is exposed and should not be pressed as it can be damaged.

The Zen Flute has small detachable parts and should be kept out of reach of children and pets.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. — Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/ TV technician for help.